

Penipu Hati

COPPER KNOB
STEPSHEETS

拍數: 32 牆數: 2 級數: Easy Intermediate
編舞者: Yva Teguh (INA) - October 2024
音樂: Penipu Hati - Tata Janeeta



INTRO : 24 count start on music (Approx 16 secs in)

#Tag 8c after wall 1 (06.00)

- 1 - 2 Cross RF over LF (1), Full Turn Left (2)
- 3 - 4 Close RF to LF with slightly bend down knees (3) , Straight up knees (4)
- 5 - 8 Sway R, L, R, L touch RF to LF.

Restart on wall 4 and wall 5 after 20c, all facing 06.00.

SECTION 1 : RF FWD, SWEEP 1/4 DIAMOND, RF FWD, FULL TURN, 1/4R NC

- 1 2& Step RF fwd, Sweep LF back to front, Cross LF over RF. Step RF to side
- 3 4& 1/8L Step LF back, Step RF back (Facing 10.30), 1/8L Step LF to side (facing 09.00)
- 5 6& RF fwd, 1/2 R Pivot on L, 1/2R pivot on R.
- 7 8& 1/4R Take a long step LF to side, Slightly cross RF behind L, Cross LF over LF.

SECTION 2 : 1/4 L STEP RF BACK, SWEEP LF CROSS BEHIND RF, WEAVE TO R. RECIVER, HALF TURN L, SWEEP LF CROSS BEHIND RF WEAVE TO R. RECOVER. 1/4 L ON LF

- 1 2& 1/4 L Step RF Back (1), Sweep LF front to back cross behind RF (2), Step RF to side (3) facing 09.00.
- 3 4& Cross LF to RF(3), Recover on RF (4), 1/4L LF fwd (&),
- 5 6& 1/4L RF back sweep LF front to back (5), Cross LF behind RF (6), Step RF to side (&) Facing 03.00.
- 7 8& Cross LF over RF (7), Recover RF (8), 1/4 L Step LF fwd. Facing 12.00

SECTION 3 : WALK FWD ON R, L, R, SPIRAL, 1/8R WALK FWD R,L, ARABESQUE, WALK BACK ON L,R,L RECOVER ON RF

- 1 2& Step RF fwd (1), Step LF fwd (2), Step RF fwd (&) facing 12.00
- 3 4& Cross LF over RF spiral turn to right (3), 1/8R step R fwd (4) facing 13.30 Step LF fwd (&)
- 5 6& Step RF fwd lift LF behind (5) Step back on LF(6), Step back on RF (&)
- 7 8 Step back on LF (7), Recover on RF

SECTION 4 : 1/4 R LF FWD, SPIRAL TURN L, LF FWD, 1/2L CHASSÉ TURN , FWD, SPIRAL TURN R, RF FWD, 1/4R LF SIDE, DRAG RF TO LF.

- 1 2 Step LF fwd (1), Cross RF over LF, Left Spiral (2),
- 3 & 4 Step LF fwd (3), RF fwd (&), 1/2L Step LF fwd.
- 5 6 Step Rf fwd (5), Cross LF over RF, Right Spiral (6)
- 7 & 8 Step RF fwd (7), 1/4R LF side (&), Drag RF touch to LF(8).

Last Update: 7 Nov 2024